

OMAP35x 0.65mm Pitch Layout Methods

Keven Coates

ABSTRACT

It is easy to see from the unique look that the OMAP35x parts have a very unusual footprint. The OMAP35x ball grid array is designed with new technology called the Via Channel[™] array, which makes significant printed circuit board (PCB) cost savings possible. If the PCB is routed correctly, this cost savings can be substantial. This application report explains how this is possible and shows several methods in which this can be done.

This document will explain methods to correctly route this BGA chip on a printed circuit board to take advantage of the features of the Via Channel array. It also shows how to route the entire OMAP35x chip in only two signal layers, using cheap PCB technology rules.

For more information regarding routing an OMAP35x system, see the SDRAM Controller Subsystem (SDRC) section in the device data sheet.

Contents

1	OMAP35x PCB Layout Technology Summary	1
2	Methods	3
3	References	7

List of Figures

1	OMAP35x Footprint With Via Channel Array	2
2	Outer Rows With Large Traces	2
3	Vias in Via Channels	3
4	Area of the Exploded Drawings for Figure 6 (top layer routing removed for clarity)	4
5	Expanded Area From Figure 4	5
6	Completed Layout in Two Signal Layers (four overall layers)	6

1 OMAP35x PCB Layout Technology Summary

1.1 Via Channel Technology

Via Channel technology is a way of depopulating balls on the BGA chip package in a shape that makes it possible to have the vias concentrated in channels. This allows several advantages.

First, the via outside diameter (also known as the annular ring) can be larger than it normally would be if it had to be placed in between the balls, since all the vias are placed in special areas called *via channels*. This makes PCB manufacturing less expensive because larger vias are possible.

Second, the vias are grouped in a radial pattern instead of a series of concentric rings around the middle of the chip, which is the case with normal BGA array PCB routing. The traces are more easily routed out of the inner parts of the chip because they are not restricted to the narrow paths in between many rows of vias.

Via Channel is a trademark of Texas Instruments. Allegro is a registered trademark of Cadence Design Systems, Inc. All other trademarks are the property of their respective owners.



OMAP35x PCB Layout Technology Summary

Figure 1 shows the resulting OMAP35x footprint.



Figure 1. OMAP35x Footprint With Via Channel Array

The unique outer row routing and the via channel inner routing are two important parts of this technology on the OMAP35x.

1.2 Outer Row Routing

For the first two rows (from the outside in) of the BGA array, the balls have been arranged to allow wider traces than would otherwise be possible. The first row (the outside row) supports any size trace desired, since the trace simply comes from the PCB ball land and goes out on the PCB. Normally, the second row traces must be routed in between the first row of the PCB ball lands. On this package, the second row traces are routed through an open channel where the BGA ball has been removed to allow wider traces. The OMAP35x parts allow a 5 mil (0.125mm) trace/space in all areas, if routed correctly.

Figure 2 shows the first two rows of the OMAP35x package and how it is possible to route large 5 mil (0.125 mm) traces and spaces in the areas of removed balls.



Figure 2. Outer Rows With Large Traces



1.3 Via Channel Inner Routing

Starting at the third row, as with any BGA package, vias are necessary. These vias are standard 18 mil (0.45mm) diameter vias with 8 mil (0.2mm) - 10 mil (0.25mm) finished hole sizes. The hole size is not important as long as the board can be built by your board shop with good yield.

As stated before, the vias are gathered in the via channels, so the only vias that need to be placed in between balls are some of the power vias in areas of ground or power copper pour. In this case, they have no regular via ring since they are located in an area of copper pour where all the surrounding balls share the same net. Since the via ring is larger than one that would normally fit in between these balls with the required clearance, the layout tool may flag a design rule check (DRC) error, however, this is a false warning since there is no risk of shorting to a nearby pad because they are all on the same net.

The rest of the vias need to be placed into the via channels as shown below. Figure 3 shows how the vias are grouped in the via channels.



Figure 3. Vias in Via Channels

1.4 The Results

If done correctly, the PCB layout rules will be as follows:

- 5 mil (0.125mm) maximum trace/space
- 18 mil (0.45mm) maximum via diameter
- No blind, stacked, buried, or micro vias necessary
- Only two signal layers needed

These are the results of the BGA escape. This result in a PCB design should be even more cost effective than a 0.8mm pitch BGA part of equal pin count.

2 Methods

There are several easier methods to route the OMAP35x. They involve copying sections and repeating them to minimize effort.

Note that the gerbers and Allegro® files are available from your TI representative so that this work is already done for you.



Methods

2.1 Copy Channel Method

This method involves placing the vias in the channels, routing them, and copying each channel to other identical channels. If the largest PCB feature sizes (above) are used, trace placement is critical to allow copying from one to the other.

Here are the steps to successfully route a Via Channel array:

- 1. Build or download the footprint for this part from your PCB layout software. Note that there is a missing ball for orientation (at J5).
- 2. Use a metric grid. This allows the software layout tool to work more effectively with the metric defined footprint and will place traces on better defined locations.
- 3. Define the trace and space width to the maximum dimension (mentioned in Section 1.4) or smaller.
- 4. Route traces from the outside row out.
- Route traces from the second row out through the missing ball areas in the first row as shown in Figure 2. Three traces will fit through each opening. This allows wider traces and spaces than when routing in between balls.



Figure 4. Area of the Exploded Drawings for Figure 6 (top layer routing removed for clarity)



- 6. Create the vias to the diameter (mentioned in Section 1.4) or smaller and place them in the via channels. Figure 5 shows how this is done.
 - a. Place the first outside via in one of the outside corners of the via channel.



A This illustration shows an even closer look at the number 1 and 2 vias on the right of the illustration. The places where the number "5" appear show the distance from the number 1 via to the surrounding area in mils (5 mils = 0.125mm). It also shows how the number 2 via is placed as close as possible to the number 1 via, but offset by 10 mils (.250mm).

Figure 5. Expanded Area From Figure 4

- b. Place the next via adjacent to the first, as close as possible, but make sure the offset is only one space and one trace width wide (10 mils or .250mm). This enables the best routing for the traces going through the trace areas from vias 3-5.
- c. The third via can go as close as possible to the second, and so on, until all the necessary vias are placed in a pattern like the one shown on Figure 3, Figure 4, and Figure 5.
- 7. On an inner layer (or bottom), route from each via out to the outside of the package as shown making sure to put the traces as close as possible, as shown in Figure 4. If you are using the maximum width trace/space dimension shown above, the placement will be tight. If this is done correctly, all but the outer two rows of the package will be routable in just one signal layer (except for the power and ground). If more than one layer is desired, feel free to switch any traces to another layer. Figure 4 shows one routing example.
- 8. Connect the vias to the BGA ball pads on the top layer as shown in Figure 3.
- 9. Copy this trace/via pattern to other identical via channels in a rotating copy method (going clockwise, for example, instead of mirroring from side to side).
- 10. Place the vias for the corners as shown in Figure 3 and Figure 4.
- 11. Route the traces out on the inner or bottom layer as shown in Figure 4.
- 12. Connect the vias to the BGA ball pads on the top layer as shown in Figure 3.
- 13. Copy this corner trace/via pattern to the other corners in a rotating copy method.
- 14. Place the power/ground vias as shown, both in between BGA ball pads and in the via channels. Placing one via for every 3-4 power/ground balls is ideal. Since the power/ground vias are placed only in locations in between four BGA ball pads that are on the same net, the warnings that the software layout tool may flag are not valid. The via becomes a hole in a copper pour area with no outside via diameter since the via would be completely engulfed in the copper pour. Since it is only adjacent to BGA ball pads in the same net, there is no possibility of shorting the via to the BGA ball pad; it is already shorted, being on the same net.

TEXAS INSTRUMENTS

Methods

www.ti.com

15. Form a copper pour area around the power/ground nets being sure to provide thermal reliefs around the BGA ball pads. These are not for thermal issues, but to ensure that the ball solder does not get wicked away (spread too thin) by the copper during reflow. This is a top layer copper pour. The lower power planes should match the same shape somewhat (if not solid) and be routed with heavy traces on the power plane. For signal integrity, it is essential to make the ground layer solid with no cuts. Cut the power plan only in a radial pattern (from the center out) once the pins are grouped. This improves signal integrity as most trace's return currents will not have to cross the gap in the power plane like they would if the cuts were perpendicular to the routing direction, which is typically from the inside of the chip out.



Figure 6. Completed Layout in Two Signal Layers (four overall layers)

It is easier to copy channels in a rotating fashion around the part than it is to copy them symmetrically. For example, when you finish routing the upper left via channel area, copy it to the area immediately to the right, and so on. Then rotate it 90° and continue down the right side, rotate it again, and continue around the bottom, etc. This tends to work better than trying to copy the upper sections and mirror them to the bottom sections.

2.2 Quadrant Method

This method is similar except that the first quadrant is routed by hand and then rotated/copied to the rest of the quadrants. Then proceed from step 14 in Section 2.1.



3 References

• SDRAM Controller Subsystem (SDRC) section of the OMAP35x datasheet

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI. Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety-critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

Products		Applications	
Amplifiers	amplifier.ti.com	Audio	www.ti.com/audio
Data Converters	dataconverter.ti.com	Automotive	www.ti.com/automotive
DSP	dsp.ti.com	Broadband	www.ti.com/broadband
Clocks and Timers	www.ti.com/clocks	Digital Control	www.ti.com/digitalcontrol
Interface	interface.ti.com	Medical	www.ti.com/medical
Logic	logic.ti.com	Military	www.ti.com/military
Power Mgmt	power.ti.com	Optical Networking	www.ti.com/opticalnetwork
Microcontrollers	microcontroller.ti.com	Security	www.ti.com/security
RFID	www.ti-rfid.com	Telephony	www.ti.com/telephony
RF/IF and ZigBee® Solutions	www.ti.com/lprf	Video & Imaging	www.ti.com/video
		Wireless	www.ti.com/wireless

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2008, Texas Instruments Incorporated